

INSTRUCTIONS:

This jig is designed to work with for 6.5mm thick fretboards. If you want a piece that is thicker or thinner than 6.5mm the radius may not be so accurate. Keep that in mind.

1. We recommend using a **Baseplate** of 750mmx300mm (the thickness is up to you), that will be right both for guitars and basses, and it will give you some extra room to move the jig front and back.

2. Use a **Fretboard Base** that's 750mmx80mmx20mm. This height - 20mm - is very important for the radius compensation. It can be made out of wood, DM or whatever you have at hand.

3. Set your router bit 6.5mm above the **Fretboard Base**. We recommend you start a little higher then gradually lower the router bit until you reach the 6.5mm.

4. Move your router front and back slowly, removing little wood in each pass.

5. **Always** use security devices when working with your router, like security goggles and gloves.

